

Part No. 302283-E Rev 00
August 2001

600 Technology Park Drive
Billerica, MA 01821-4130

Installing Hardware Options for the Contivity VPN Switch

NORTEL
NETWORKS™

Copyright © 2001 Nortel Networks

All rights reserved. August 2001.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks Inc.

The software described in this document is furnished under a license agreement and may be used only in accordance with the terms of that license. The software license agreement is included in this document.

Trademarks

Nortel Networks, the Nortel Networks logo, the Globemark, Unified Networks, and Contivity are trademarks of Nortel Networks.

Microsoft, Windows, and Windows NT and MS-DOS are trademarks of Microsoft Corporation.

Adobe and Acrobat Reader are trademarks of Adobe Systems Incorporated.

Restricted rights legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

Statement of conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks Inc. reserves the right to make changes to the products described in this document without notice.

Nortel Networks Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product may be Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

USA requirements only

Federal Communications Commission (FCC) Compliance Notice: Radio Frequency Notice

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy. If it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to take whatever measures may be necessary to correct the interference at their own expense.

European requirements only

EN 55 022 statement (Class A)

This is to certify that the Nortel Networks Contivity VPN Switch is shielded against the generation of radio interference in accordance with the application of Council Directive 89/336/EEC, Article 4a. Conformity is declared by the application of EN 55 022 Class A (CISPR 22).

Warning: This is a Class A product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take appropriate measures.

Achtung: Dieses ist ein Gerät der Funkstörgrenzwertklasse A. In Wohnbereichen können bei Betrieb dieses Gerätes Rundfunkstörungen auftreten, in welchen Fällen der Benutzer für entsprechende Gegenmaßnahmen verantwortlich ist.

Attention: Ceci est un produit de Classe A. Dans un environnement domestique, ce produit risque de créer des interférences radioélectriques, il appartiendra alors à l'utilisateur de prendre les mesures spécifiques appropriées.

To maintain compliance with FCC radio frequency emission limits, shielded cables are required to connect equipment to other Class A certified devices and the use of quadshield, RG-6/U type CATV cable is required for connection to the CATV system. Any changes or modifications may void the user's authorization to operate this equipment.

EN 55 022 statement (Class B)

This is to certify that the Nortel Networks Contivity 1600 and 2600 are shielded against the generation of radio interference in accordance with the application of Council Directive 89/336/EEC, Article 4a. Conformity is declared by the application of EN 55 022 Class B (CISPR 22).

Compliance is dependent upon the use of shielded Nortel Networks Contivity 1600 or 2600.

EC Declaration of Conformity

These products conform to the provisions of the R&TTE Directive 1999/5/EC.

Japan/Nippon requirements only

Voluntary Control Council for Interference (VCCI) statement (Class A)

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Voluntary Control Council for Interference (VCCI) statement (Class B Contivity 1600 and 2600)

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス B 情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

Taiwan requirements

Bureau of Standards, Metrology and Inspection (BSMI) statement

警告使用者:

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

Canada requirements only

Canadian Department of Communications Radio Interference Regulations

This digital apparatus (Contivity VPN Switch) does not exceed the Class A limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Règlement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique (Contivity VPN Switch) respecte les limites de bruits radioélectriques visant les appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada.

Canadian Department of Communications Radio Interference Regulations

This digital apparatus (Contivity 1600 and Contivity 2600) does not exceed the Class B limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Règlement sur le brouillage radioélectrique du ministère des Communications (Classe B)

Cet appareil numérique (Contivity 1600 and Contivity 2600) respecte les limites de bruits radioélectriques visant les appareils numériques de classe B prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada.

Canada CS-03 rules and regulations

Notice: The Industry Canada label identifies certified equipment. This certification means that the equipment meets telecommunications network protective, operational and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent the degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

Notice: For equipment using loopstart lines, please note that the Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5. The REN is located on the "FCC Rules Part 68" label located on the bracket of the module, or on the back of the unit.

Canada CS-03 -- règles et règlements

Avis: L'étiquette d'Industrie Canada identifie le matériel homologué. Cette étiquette certifie que le matériel est conforme aux normes de protection, d'exploitation et de sécurité des réseaux de télécommunications, comme le prescrivent les documents concernant les exigences techniques relatives au matériel terminal. Le Ministère n'assure toutefois pas que le matériel fonctionnera à la satisfaction de l'utilisateur.

Avant d'installer ce matériel, l'utilisateur doit s'assurer qu'il est permis de le raccorder aux installations de l'entreprise locale de télécommunication. Le matériel doit également être installé en suivant une méthode acceptée de raccordement. L'abonné ne doit pas oublier qu'il est possible que la conformité aux conditions énoncées ci-dessus n'empêche pas la dégradation du service dans certaines situations.

Les réparations de matériel homologué doivent être coordonnées par un représentant désigné par le fournisseur. L'entreprise de télécommunications peut demander à l'utilisateur de débrancher un appareil à la suite de réparations ou de modifications effectuées par l'utilisateur ou à cause de mauvais fonctionnement.

Pour sa propre protection, l'utilisateur doit s'assurer que tous les fils de mise à la terre de la source d'énergie électrique, des lignes téléphoniques et des canalisations d'eau métalliques, s'il y en a, sont raccordés ensemble. Cette précaution est particulièrement importante dans les régions rurales.

Avertissement: L'utilisateur ne doit pas tenter de faire ces raccordements lui-même; il doit avoir recours à un service d'inspection des installations électriques, ou à un électricien, selon le cas.

Avis: Veuillez prendre note que pour tout appareillage supportant des lignes de type "loopstart," l'indice d'équivalence de la sonnerie (IES) assigné à chaque dispositif terminal indique le nombre maximal de terminaux qui peuvent être raccordés à une interface. La terminaison d'une interface téléphonique peut consister en une combinaison de quelques dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5. Le REN figure sur l'étiquette "FCC Rules Part 68" située sur le support du module ou à l'arrière de l'unité.

FCC Part 68 compliance statement

This equipment complies with Part 68 of FCC Rules. All direct connections to telephone network lines must be made using standard plugs and jacks compliant with FCC Part 68. Please note the following:

1. You are required to request service from the telephone company before you connect the unit to a network. When you request service, you must provide the telephone company with the following data:
 - When you request T1 Service, you must provide the telephone company with
 - The Facility Interface Code
Provide the telephone company with all the codes below:
 - 04DU9-BN (1.544 MB, D4 framing format)
 - 04DU9-DN (1.544 MB, D4 framing format with B8ZF coding)
 - 04DU9-1KN (1.544 MB, ESF framing format)
 - 04DU9-1SN (1.544 MB, ESF framing format with B8ZF coding)
 - 04DU9-1ZN (1.544 MB, ANSI ESF and ZBT SI without line power)
 The telephone company will select the code it has available.
 - The Service Order Code(s) (SOC): 6.0Y
 - The required Universal Service Order Code (USOC) jack: RJ48C
 - When you request ISDN "U" Interface Service, you must provide the telephone company with
 - The Facility Interface Code: 02IS5
 - The Service Order Code(s) (SOC): 6.0F
 - The required Universal Service Order Code (USOC) jack: RJ49C
 - When you request ISDN "S/T" Interface Service, you must provide the telephone company with
 - The Service Order Code(s) (SOC): 6.0P
 - The make, model number, and FCC Registration number of the NT1

Note: ISDN S/T cannot be directly connected to the network.
 - When you request Primary Rate ISDN Service, you must provide the telephone company with
 - The Facility Interface Code: 04DU9-1SN (1.544 MB, ESF framing format with B8ZF coding)
 - The Service Order Code(s) (SOC): 6.0Y
 - The required Universal Service Order Code (USOC) jack: RJ48C

2. Your telephone company may make changes to its facilities, equipment, operations, or procedures that could affect the proper functioning of your equipment. The telephone company will notify you in advance of such changes to give you an opportunity to maintain uninterrupted telephone service.
3. If the unit causes harm to the telephone network, the telephone company may temporarily discontinue your service. If possible, they will notify you in advance, but if advance notice is not practical, you will be notified as soon as possible and will be informed of your right to file a complaint with the FCC.
4. If you experience trouble with the unit, please contact the Nortel Networks Technical Solutions Center in your area for service or repairs. Repairs should be performed only by service personnel authorized by Nortel Networks.

North America (800) 4NORTEL or (800) 466-7835

EMEA (33) (4) 92-966-968

Asia Pacific (61) (2) 9927-8800

China (800) 810-5000

5. You are required to notify the telephone company when you disconnect the unit from the network.

Nortel Networks Inc. software license agreement

NOTICE: Please carefully read this license agreement before copying or using the accompanying software or installing the hardware unit with pre-enabled software (each of which is referred to as “Software” in this Agreement). BY COPYING OR USING THE SOFTWARE, YOU ACCEPT ALL OF THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. THE TERMS EXPRESSED IN THIS AGREEMENT ARE THE ONLY TERMS UNDER WHICH NORTEL NETWORKS WILL PERMIT YOU TO USE THE SOFTWARE. If you do not accept these terms and conditions, return the product, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

1. License grant. Nortel Networks Inc. (“Nortel Networks”) grants the end user of the Software (“Licensee”) a personal, nonexclusive, nontransferable license: a) to use the Software either on a single computer or, if applicable, on a single authorized device identified by host ID, for which it was originally acquired; b) to copy the Software solely for backup purposes in support of authorized use of the Software; and c) to use and copy the associated user manual solely in support of authorized use of the Software by Licensee. This license applies to the Software only and does not extend to Nortel Networks Agent software or other Nortel Networks software products. Nortel Networks Agent software or other Nortel Networks software products are licensed for use under the terms of the applicable Nortel Networks Inc. Software License Agreement that accompanies such software and upon payment by the end user of the applicable license fees for such software.

2. Restrictions on use; reservation of rights. The Software and user manuals are protected under copyright laws. Nortel Networks and/or its licensors retain all title and ownership in both the Software and user manuals, including any revisions made by Nortel Networks or its licensors. The copyright notice must be reproduced and included with any copy of any portion of the Software or user manuals. Licensee may not modify, translate, decompile, disassemble, use for any competitive analysis, reverse engineer, distribute, or create derivative works from the Software or user manuals or any copy, in whole or in part. Except as expressly provided in this Agreement, Licensee may not copy or transfer the Software or user manuals, in whole or in part. The Software and user manuals embody Nortel Networks’ and its licensors’ confidential and proprietary intellectual property. Licensee shall not sublicense, assign, or otherwise disclose to any third party the Software, or any information about the operation, design, performance, or implementation of the Software and user manuals that is confidential to Nortel Networks and its licensors; however, Licensee may grant permission to its consultants, subcontractors, and agents to use the Software at Licensee’s facility, provided they have agreed to use the Software only in accordance with the terms of this license.

3. Limited warranty. Nortel Networks warrants each item of Software, as delivered by Nortel Networks and properly installed and operated on Nortel Networks hardware or other equipment it is originally licensed for, to function substantially as described in its accompanying user manual during its warranty period, which begins on the date Software is first shipped to Licensee. If any item of Software fails to so function during its warranty period, as the sole

remedy Nortel Networks will at its discretion provide a suitable fix, patch, or workaround for the problem that may be included in a future Software release. Nortel Networks further warrants to Licensee that the media on which the Software is provided will be free from defects in materials and workmanship under normal use for a period of 90 days from the date Software is first shipped to Licensee. Nortel Networks will replace defective media at no charge if it is returned to Nortel Networks during the warranty period along with proof of the date of shipment. This warranty does not apply if the media has been damaged as a result of accident, misuse, or abuse. The Licensee assumes all responsibility for selection of the Software to achieve Licensee's intended results and for the installation, use, and results obtained from the Software. Nortel Networks does not warrant a) that the functions contained in the software will meet the Licensee's requirements, b) that the Software will operate in the hardware or software combinations that the Licensee may select,

c) that the operation of the Software will be uninterrupted or error free, or d) that all defects in the operation of the Software will be corrected. Nortel Networks is not obligated to remedy any Software defect that cannot be reproduced with the latest Software release. These warranties do not apply to the Software if it has been (i) altered, except by Nortel Networks or in accordance with its instructions; (ii) used in conjunction with another vendor's product, resulting in the defect; or (iii) damaged by improper environment, abuse, misuse, accident, or negligence. THE FOREGOING WARRANTIES AND LIMITATIONS ARE EXCLUSIVE REMEDIES AND ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Licensee is responsible for the security of its own data and information and for maintaining adequate procedures apart from the Software to reconstruct lost or altered files, data, or programs.

4. Limitation of liability. IN NO EVENT WILL NORTEL NETWORKS OR ITS LICENSORS BE LIABLE FOR ANY COST OF SUBSTITUTE PROCUREMENT; SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES; OR ANY DAMAGES RESULTING FROM INACCURATE OR LOST DATA OR LOSS OF USE OR PROFITS ARISING OUT OF OR IN CONNECTION WITH THE PERFORMANCE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL THE LIABILITY OF NORTEL NETWORKS RELATING TO THE SOFTWARE OR THIS AGREEMENT EXCEED THE PRICE PAID TO NORTEL NETWORKS FOR THE SOFTWARE LICENSE.

5. Government licensees. This provision applies to all Software and documentation acquired directly or indirectly by or on behalf of the United States Government. The Software and documentation are commercial products, licensed on the open market at market prices, and were developed entirely at private expense and without the use of any U.S. Government funds. The license to the U.S. Government is granted only with restricted rights, and use, duplication, or disclosure by the U.S. Government is subject to the restrictions set forth in subparagraph (c)(1) of the Commercial Computer Software—Restricted Rights clause of FAR 52.227-19 and the limitations set out in this license for civilian agencies, and subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause of DFARS 252.227-7013, for agencies of the Department of Defense or their successors, whichever is applicable.

6. Use of software in the European Community. This provision applies to all Software acquired for use within the European Community. If Licensee uses the Software within a country in the European Community, the Software Directive enacted by the Council of European Communities Directive dated 14 May, 1991, will apply to the examination of the Software to facilitate interoperability. Licensee agrees to notify Nortel Networks of any such intended examination of the Software and may procure support and assistance from Nortel Networks.

7. Term and termination. This license is effective until terminated; however, all of the restrictions with respect to Nortel Networks' copyright in the Software and user manuals will cease being effective at the date of expiration of the Nortel Networks copyright; those restrictions relating to use and disclosure of Nortel Networks' confidential information shall continue in effect. Licensee may terminate this license at any time. The license will automatically terminate if Licensee fails to comply with any of the terms and conditions of the license. Upon termination for any reason, Licensee will immediately destroy or return to Nortel Networks the Software, user manuals, and all copies. Nortel Networks is not liable to Licensee for damages in any form solely by reason of the termination of this license.

8. Export and re-export. Licensee agrees not to export, directly or indirectly, the Software or related technical data or information without first obtaining any required export licenses or other governmental approvals. Without limiting the foregoing, Licensee, on behalf of itself and its subsidiaries and affiliates, agrees that it will not, without first obtaining all

Contents

Preface	13
Related publications	14
Text conventions	14
Acronyms	16
Hard-copy technical manuals	17
How to get help	17
 Chapter 1	
Contivity 4600 Option Installation	19
Opening the Contivity 4600	19
Contivity 4600 system board layout	22
Installing Contivity 4600 LAN/WAN and hardware accelerator cards	23
Installing Contivity 4600 DIMMs	24
Replacing a Contivity 4600 power supply	25
Replacing a Contivity 4600 hard disk drive	27
 Chapter 2	
Contivity 4500 Option Installation	31
Opening the Contivity 4500	31
Removing the Contivity 4500 front bezel	31
Contivity 4500 system board layout	34
Installing Contivity 4500 LAN/WAN and hardware accelerator option cards	36
Installing Contivity 4500 DIMMs	38
Replacing a Contivity 4500 power supply	40
Replacing a Contivity 4500 hard disk drive	41
 Chapter 3	
Contivity 2500/2000/4000 Option Installation	43
Opening the Contivity 2500/2000/4000	43
Removing the Contivity 2500/2000/4000 front bezel	43
Removing the Contivity 2500/2000/4000 top cover	45
Contivity 2500/2000/4000 system board layout	46

Installing Contivity 2500/2000/4000 LAN/WAN option cards	48
Installing Contivity 2500/2000/4000 DIMMs	49
Replacing a Contivity 4000 power supply	50
Replacing a Contivity 4000 disk drive	52
Installing Contivity 2500/2000/4000 DIMMs	54
Memory option	55

Chapter 4

Contivity 2600 Option Installation 57

Opening the Contivity 2600	57
Removing the Contivity 2600 front bezel	58
Removing the Contivity 2600 top cover	59
Contivity 2600 system board layout	60
Installing LAN/WAN and hardware accelerator option cards	62
Installing Contivity 2600 DIMMs	64
Memory option	65

Chapter 5

Contivity 1600 Option Installation 67

Opening the Contivity 1600	67
Removing the Contivity 1600 front bezel	68
Removing the Contivity 1600 top cover	69
Contivity 1600 system board layout	71
Installing Contivity 1600 option cards	72
Installing Contivity 1600 DIMMs	75
Memory option	76

Chapter 6

Contivity 600 Option Installation 77

Opening the Contivity 600	78
Contivity 600 system board layout	80
Installing Contivity 600 option cards	81
Memory option	83

Index 85

Figures

Figure 1	Removing the Contivity 4600 front bezel	20
Figure 2	Contivity 4600 front components	21
Figure 3	Sample Contivity 4600 system board	22
Figure 4	Installing Contivity 4600 LAN/WAN and hardware accelerator cards	23
Figure 5	Installing Contivity 4600 DIMMs	25
Figure 6	Removing a Contivity 4600 power supply	26
Figure 7	Removing a Contivity 4600 hard disk drive	28
Figure 8	Removing the Contivity 4500 front bezel	32
Figure 9	Contivity 4500 front components	33
Figure 10	Sample Contivity 4500 system board	35
Figure 11	Installing 4500 LAN/WAN and hardware accelerator option cards	37
Figure 12	Installing Contivity 4500 DIMMs	38
Figure 13	Removing a Contivity 4500 power supply	40
Figure 14	Removing a Contivity 4500 hard disk drive	42
Figure 15	Removing the Contivity 2500/2000/4000 front bezel	44
Figure 16	Removing the Contivity 2500/2000/4000 top cover	45
Figure 17	Sample Contivity 2500/2000 system board	46
Figure 18	Sample Contivity 4000 system board	47
Figure 19	Installing 2500/2000/4000 LAN/WAN option cards	48
Figure 20	Installing Contivity 2500/2000/4000 DIMMs	50
Figure 21	Removing a Contivity 4000 power supply	51
Figure 22	Removing a Contivity 4000 hard disk drive	53
Figure 23	Installing Contivity 2500/2000/4000 DIMMs	54
Figure 24	Removing the Contivity 2600 front bezel	58
Figure 25	Removing the Contivity 2600 top cover	60
Figure 26	The Contivity 2600 system board	61
Figure 27	Installing LAN/WAN or hardware accelerator cards	62
Figure 28	Installing Contivity 2600 DIMMs	64
Figure 29	Removing the Contivity 1600 front bezel	68

Figure 30	Removing the Contivity 1600 power cord	69
Figure 31	Removing the Contivity 1600 top cover	70
Figure 32	Contivity 1600 system board	71
Figure 33	Removing the Contivity 1600 power cord	72
Figure 34	Installing Contivity 1600 LAN/WAN option cards	73
Figure 35	Installing Contivity 1600 option cards	74
Figure 36	Installing Contivity 1600 DIMMs	75
Figure 37	Removing the bottom screws	79
Figure 38	Removing the system from the chassis	80
Figure 39	Contivity 600 system board	81
Figure 40	Replacing the system into the chassis	82

Preface

This document describes how Nortel Networks* trained service personnel can install or replace hardware components for models 4600, 4500, 4000, 2600, 2500, 2000, 1600, and 600 of the Contivity* products. The options include:

- Installing LAN and WAN option cards
- Installing hardware accelerator PCI cards
- Adding or replacing memory
- Replacing a power supply (4600, 4500, and 4000 only)
- Replacing a hard disk drive (4600, 4500, and 4000 only)

To install LAN, WAN, or hardware accelerator PCI cards and for system recovery operations, you must remove the front bezel, the top cover, and/or the rear I/O panel tray, depending on the type of Contivity product you are servicing. The procedures for each Contivity model are described in the following chapters.



Warning: Only Nortel Networks trained service personnel should change existing hardware configurations. *Improper handling of internal components or assemblies, with the power connected, could cause severe injury.*



Warning: Note that some models must be returned to Nortel Networks Manufacturing via your Customer Service Representative for repair. **Do not attempt to make any changes** to these models, because untrained individuals could be harmed, you could invalidate your warranty, or you could possibly cause irreparable damage to the equipment.

This guide refers to the Contivity 4600, 4500, 4000, 2600, 2000, 1600, and 600 as *the switch*. It assumes that you are familiar with Web browsers and their general operation.

Related publications

The following list shows the associated documentation that you will need to configure and manage the switch.

- *Contivity VPN Switch Release Notes* provide the latest information, including known problems, workarounds, and special considerations.
- *Configuring the Contivity VPN Switch* (included on the CD) provides complete detailson how to configure, monitor, and troubleshoot the switch.
- *Getting Started with the Contivity xxxx* or *Installing the Contivity xxxx* (included on the CD) provides complete details to help you set up and get started using your switch.

Text conventions

This guide uses the following text conventions:

- | | |
|--------------------------|---|
| angle brackets (< >) | Indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when entering the command.
Example: If the command syntax is
<code>ping <ip_address></code> , you enter
<code>ping 192.32.10.12</code> |
| bold Courier text | Indicates command names, options, and text that you need to enter.
Example: Use the dinfo command.
Example: Enter show ip {alerts routes} . |

braces ({})	<p>Indicate required elements in syntax descriptions where there is more than one option. You must choose only one of the options. Do not type the braces when entering the command.</p> <p>Example: If the command syntax is <code>show ip {alerts routes}</code>, you must enter either <code>show ip alerts</code> or <code>show ip routes</code>, but not both.</p>
brackets ([])	<p>Indicate optional elements in syntax descriptions. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is <code>show ip interface [-alerts]</code>, you can enter either <code>show ip interface</code> or <code>show ip interface -alerts</code>.</p>
ellipsis points (. . .)	<p>Indicate that you repeat the last element of the command as needed.</p> <p>Example: If the command syntax is <code>ethernet/2/1 [<parameter> <value>] . . .</code>, you enter <code>ethernet/2/1</code> and as many parameter-value pairs as needed.</p>
<i>italic text</i>	<p>Indicates new terms, book titles, and variables in command syntax descriptions. Where a variable is two or more words, the words are connected by an underscore.</p> <p>Example: If the command syntax is <code>show at <valid_route></code>, <i>valid_route</i> is one variable and you substitute one value for it.</p>
plain Courier text	<p>Indicates command syntax and system output, for example, prompts and system messages.</p> <p>Example: <code>Set Trap Monitor Filters</code></p>
separator (->)	<p>Shows menu paths.</p> <p>Example: <code>Protocols > IP</code> identifies the IP option on the Protocols menu.</p>

vertical line ()	Separates choices for command keywords and arguments. Enter only one of the choices. Do not type the vertical line when entering the command. Example: If the command syntax is <code>show ip {alerts routes}</code> , you enter either <code>show ip alerts</code> or <code>show ip routes</code> , but not both.
asterisk (*)	Indicates a trademark. See the Title Page for trademark information. Example: Contivity*

Acronyms

This guide uses the following acronyms:

CSU/DSU	Channel Service Unit/ Digital Service Unit
DIMM	Dual inline memory module
DTE	Data Terminal Equipment
ERC	Express Routing Code
FTP	File Transfer Protocol
HSSI	high speed serial interface
HTTP	HyperText Transfer Protocol
IP	Internet Protocol
IPMI	Intelligent Platform Management Interface
LAN	Local area network
LED	Light emitting diode
PCI	Peripheral component interconnect
PDN	Public data network
SCSI	Small computer system interface
SNMP	Simple Network Management Protocol
TCP	Transmission Control Protocol

URL	Uniform Resource Locator
VPN	Virtual private network
WAN	Wide area network

Hard-copy technical manuals

You can print selected technical manuals and release notes free, directly from the Internet. Go to the www.nortelnetworks.com/documentation URL. Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Use Adobe* Acrobat Reader* to open the manuals and release notes, search for the sections you need, and print them on most standard printers. Go to Adobe Systems at the www.adobe.com URL to download a free copy of the Adobe Acrobat Reader*.

You can purchase selected documentation sets, CDs, and technical publications through the Internet at the www1.fatbrain.com/documentation/nortel/ URL.

How to get help

If you purchased a service contract for your Nortel Networks product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel Networks service program, contact one of the following Nortel Networks Technical Solutions Centers:

Technical Solutions Center	Telephone
Europe, Middle East, and Africa	(33) (4) 92-966-968
North America	(800) 2LANWAN or (800) 252-6926
Asia Pacific	(61) (2) 9927-8800
China	(800) 810-5000

An Express Routing Code (ERC) is available for many Nortel Networks products and services. When you use an ERC, your call is routed to a technical support person who specializes in supporting that product or service. To locate an ERC for your product or service, go to the www12.nortelnetworks.com/ URL and click Express Call Routing at the bottom of the page.

Chapter 1

Contivity 4600 Option Installation

This section describes how to install or replace hardware components for the Contivity 4600.



Caution: Wear an antistatic band when handling electronic components for the switch to avoid damaging them.



Warning: Turn off the switch and unplug both power cords before installing LAN and WAN cards or system memory.

Opening the Contivity 4600

To replace power supplies, replace hard disk drives, or access the diskette drive for system recovery operations, you must remove the switch's front bezel.



Note: Removing the front bezel on the Contivity 4600 activates the chassis intrusion alarm on power only. This intrusion is reported to the system log file.


The first few times you remove the front bezel it might seem to resist removal. This is simply because the ball stud and sockets are new. After a few times, removal is easier. Remove the switch front bezel as follows:

- 1 Insert a flat-head screwdriver into the slots on the lower left and right sides of the chassis, and pry the bezel forward.
- 2 Slide your fingers between the front bezel and the switch.
- 3 Pull the bezel forward firmly, separating the ball studs on the bezel from the sockets on the chassis.

Figure 1 shows you how to remove the front bezel from the Contivity 4600. You do not need to turn off the switch to remove the front bezel when installing a power supply or hard disk drive.

Figure 1 Removing the Contivity 4600 front bezel


Using a phillips screwdriver, rotate screws a quarter turn anti-clockwise (top right and left corners), then separate ball stud on bezel from socket on chassis (middle of both sides and bottom right and left corners)



CS460005A

Figure 2 shows the Contivity 4600 front components.

Figure 2 Contivity 4600 front components



CS460006A

Contivity 4600 system board layout


This section shows the Contivity 4600 system board.



Warning: Only Nortel Networks trained service personnel should change existing hardware configurations. *Improper handling of internal components or assemblies, with the power connected, could cause severe injury.*

Figure 3 shows a sample Contivity 4600 system board, including the Dual Inline Memory Modules (DIMMs) and peripheral component interconnect (PCI) slots.

Figure 3 Sample Contivity 4600 system board




CS460007A

Installing Contivity 4600 LAN/WAN and hardware accelerator cards

This section describes how you install option cards in the switch option card slide-out tray. The following procedure is for Nortel Networks trained service personnel only.

- 1 Turn off the switch and unplug both power cords from the power source.
- 2 Unscrew the four slotted thumb-screws securing the slide-out tray. Pull out the tray by gripping it with the screws. It will only pull out halfway.
- 3 Remove the filler panel screw and pull out the slot filler panel.
- 4 Slide the option card into the intended slot. Make sure the card seats firmly and evenly in the card slot. If the card is not seated properly, it will not work. Populate the slots from Slot 1 to Slot 6 (top to bottom), in that order, as shown in [Figure 4](#).

Figure 4 Installing Contivity 4600 LAN/WAN and hardware accelerator cards



- 5 Secure the option card in the tray with the slot filler panel screw.
- 6 Push in the tray by gripping it with the screws. Tighten the four slotted thumb-screws securing the slide-out tray.

- 7 Plug in both power cords to the power source and turn on the switch.




Caution: Be careful when inserting option cards into the Contivity 4600, because the slide-out tray is not fully supported once pulled out. You should support the back of the tray with your hand while inserting an option card.

Installing Contivity 4600 DIMMs

[Figure 6](#) shows you how to unlock a DIMM in the Contivity 4600, and remove or install a DIMM. Install a DIMM in the next available slot (for example, if the DIMM #1 slot is populated, then add the next DIMM to the DIMM #2 slot).

To install a DIMM in the Contivity 4600, follow these steps:

- 1 Turn off the switch and unplug both power cords from the power source.
- 2 Unscrew the four slotted thumb-screws securing the slide-out tray. Pull out the tray by gripping it with the screws. It will only pull out halfway.
- 3 Unscrew the slide-out tray at the back of the unit and pull it out using the thumb screws.
- 4 Remove the support bracket by loosening the two secured captive screws and the rear Phillips screw.
- 5 Press down the locking levers on both sides of the next available DIMM slot.
- 6 Place a new DIMM in the slot, making sure to properly position the DIMM's alignment keys, as shown in [Figure 5](#).

Figure 5 Installing Contivity 4600 DIMMs


- 7 Pull up the locking levers on both sides of the next available DIMM, and snap the DIMM into its socket.
- 8 Replace the support bracket by tightening the two secured captive screws and the rear Phillips screw.
- 9 Push in the slide-out tray and tighten the thumb-screws.

Replacing a Contivity 4600 power supply

To remove the power supply:

- 1 Remove the front bezel as shown in [Figure 1](#).
- 2 Use a flat-head screwdriver to unscrew the top and bottom power supply screws, as shown in [Figure 6](#).

Figure 6 Removing a Contivity 4600 power supply



CS460010A

- 3** Grab the handle and pull the power supply firmly, until the device disengages. Be careful of the sharp sheet-metal edges.
- 4** Insert the new power supply. Make sure it seats firmly in its socket and is locked in. Be sure the green power LED on the front of the power supply is on.
- 5** Secure the power supply screws tightly with a screwdriver.
- 6** Replace the front bezel.

Replacing a Contivity 4600 hard disk drive

Figure 7 shows you how to replace Contivity 4600 hard disk drives for the switch.



Caution: Hard disks are not hot-swappable.

To replace a hard disk drive, you must do the following:

Software

First save any data that has not yet been saved to the hard disk from the disk cache:

- 1 Use your Web browser to navigate to the switch, and go to the Admin→File System display.
- 2 Click the button “Prepare selected device for removal.”

Hardware

Next, remove the switch’s front bezel as shown in Figure 1, and then follow these steps:


- 1 Insert and turn the hard disk drive key to the right. The LED becomes a “U” for unlocked.



Note: Turning the key shuts off the power to the hard disk drive.

- 2 Pull the handle to remove the hard disk drive, as shown in Figure 7.

Figure 7 Removing a Contivity 4600 hard disk drive



CS460011A

- 3** Insert the replacement hard drive fully, and lock it by turning the key clockwise. Make sure the hard disk drive LED shows the proper drive number.
- 4** Replace the front bezel.

If you need to reload the software on the disk, see the information on using the recovery diskette in the *Installing the Contivity 4600* book.

Software

Enable the switch by following these steps:

- 1** Use your Web browser to navigate to the switch, and go to the Admin→File System display.
- 2** Click on the drive and click the Enable button.

Chapter 2

Contivity 4500 Option Installation

This section describes how to install or replace hardware components for the Contivity 4500.



Warning: Wear an antistatic band when handling electronic components for the Contivity switch to avoid damaging them.



Note: Turn off the Contivity switch and unplug it before installing LAN or WAN cards, or system memory.

Opening the Contivity 4500

To replace power supplies, replace hard disk drives, or access the Contivity 4500's diskette drive for system recovery operations, you must remove the switch's front bezel. To install LAN or WAN cards, or install additional memory, you must remove the front bezel and then remove the switch's top cover as well.

Removing the Contivity 4500 front bezel



Note: Removing the front bezel on the Contivity 4500 system activates the chassis intrusion alarm only if the switch is turned on. This intrusion is reported to the system log file.


The first few times you remove the front bezel it will be somewhat difficult to remove. This is because the ball stud and sockets are new. After a few times, removal is easier. Remove the switch's front bezel as follows:

- 1 Insert a flat-head screwdriver into the slots on the lower left and right sides of the chassis, and pry the bezel forward.
- 2 Slide your fingers between the front bezel and the switch.
- 3 Pull the bezel forward firmly, separating the ball studs on the bezel from the sockets on the chassis.

Figure 8 shows you how to remove the front bezel from the switch. You do not need to turn off the switch to remove the front bezel.

Figure 8 Removing the Contivity 4500 front bezel

Using a screwdriver
separate ball stud
on bezel from socket
on chassis (4 corners)




Remove the Contivity 4500 front bezel to:

- Replace a power supply.
- Replace a hard disk drive.
- Insert the recovery diskette.

Figure 9 shows the Contivity 4500 front components.

Figure 9 Contivity 4500 front components



Contivity 4500 system board layout

This section describes installing option cards onto the system board.



Warning: Only Nortel Networks trained service personnel should change existing hardware configurations. *Improper handling of internal components or assemblies, with the power connected, could cause severe injury.*




Note: Wear an antistatic band when handling electronic components for the switch to avoid damaging them.



Warning: Turn off the switch and unplug both power cords before installing LAN and WAN cards or system memory.

Figure 10 shows the Contivity 4500 system board, in particular the DIMMs and option card slots.

Figure 10 Sample Contivity 4500 system board



CS450013A

Installing Contivity 4500 LAN/WAN and hardware accelerator option cards

This section describes how you install option cards into the Contivity 4500 option card slide-out tray. The following procedure is for Nortel Networks trained service personnel only.


- 1 Turn off the switch and unplug both power cords from the power source.
- 2 Unscrew the four slotted thumb screws securing the slide-out tray. Pull out the tray by gripping it with the screws. It will only pull out half way.
- 3 Remove the filler panel screw and pull out the slot filler panel.
- 4 Slide the option card into the intended slot. Make sure the card seats firmly and evenly into the card slot. If the card is not seated properly, it will not work. Populate the slots from Slot 1 to Slot 6, in that order.
- 5 Secure the option card in the tray with the slot filler panel screw.
- 6 Push in the tray by gripping it with the screws. Tighten the four slotted thumb screws securing the slide-out tray.
- 7 Plug in both power cords to the power source and turn on the switch.



Caution: Be careful when inserting option cards into the Contivity 4500, because the slide-out tray is not fully supported once pulled out. You should support the back of the tray with your hand while inserting an option card.

Figure 11 shows you how to install LAN, WAN, or hardware accelerator option cards into the Contivity 4500. You can use the 6 slots for any mix of LAN and WAN or hardware accelerator cards; however, **you must populate the slots from bottom to top, in that order.**


Figure 11 Installing 4500 LAN/WAN and hardware accelerator option cards



Installing Contivity 4500 DIMMs

Figure 12 shows you how to unlock a Dual Inline Memory Module (DIMM) in the Contivity 4500, and remove or install a DIMM. Install a DIMM in the next available slot (for example, if the DIMM #1 slot is populated, then add the next DIMM to the DIMM #2 slot).

Figure 12 Installing Contivity 4500 DIMMs



CS450015A

To install a DIMM into the Contivity 4500, follow these steps:

- 1 Turn off the switch.
- 2 Remove the power cords.
- 3 Unscrew the slide-out tray at the back of the unit and pull it out using the thumb screws.
- 4 Remove the support bracket by loosening the two secured captive screws and the rear Phillips screw.
- 5 Press down the locking levers on both sides of the next available DIMM slot to allow the new DIMM to be inserted.
- 6 Place the new DIMM in the slot, making sure to properly position the DIMM's alignment keys. Make sure the DIMM is pressed firmly into the socket.
- 7 Pull up the locking levers on both sides of the DIMM, and snap the DIMM into the socket.
- 8 Replace the support bracket by tightening the two secured captive screws and the rear Phillips screw.
- 9 Push in the slide-out tray and tighten the thumb screws.




Caution: Be careful when inserting option cards into the Contivity 4500, because the slide-out tray is not fully supported once pulled out. You should support the back of the tray with your hand while inserting an option card.

Replacing a Contivity 4500 power supply

Figure 13 shows you how to replace a hot-swappable power supply for the Contivity 4500.

Figure 13 Removing a Contivity 4500 power supply



CS460010A

To remove the power supply:

- 1 Remove the front bezel as shown in [Figure 8](#).
- 2 Use a flat-head screwdriver to unscrew the top and bottom power supply screws.
- 3 Grab the handle and pull the power supply firmly, until the device disengages. Avoid the sharp sheet-metal edges.

- 4 Insert the new power supply. Make sure the power supply seats firmly in its socket and is locked in. Be sure the green power LED on the front of the power supply is on.
- 5 Secure the power supply screws tightly with a screwdriver.
- 6 Replace the front bezel.

Replacing a Contivity 4500 hard disk drive



Warning: Contivity 4500 hard disks are not hot-swappable.

When swapping a disk drive, you must first perform the steps listed below to ready the switch for the swap. This process is referred to as “warm-swapping” a disk drive.

Software

First save any data that has not yet been saved to the hard disk from the disk cache:

- 1 Launch a Web browser to the switch, and go to the Admin→File System display.
- 2 Click the button “Prepare selected device for removal.”

Hardware

Remove the switch’s front bezel as shown in [Figure 8](#), and then follow these steps:


- 1 Insert and turn the hard disk drive key to the right. The LED becomes a “U” for unlocked.



NOTE: Turning the key shuts off the power to the hard disk drive.

- 2 Pull the handle to remove the hard disk drive as shown in [Figure 14](#).

Figure 14 Removing a Contivity 4500 hard disk drive



CS460011A

- 3** Insert the replacement hard drive fully, and lock it by turning the key clockwise. Make sure the hard disk drive LED shows the proper drive number.
- 4** Replace the front bezel.
- 5** Reload the software on the disk. Refer to “Using the Recovery Diskette” in *Installing the Contivity 4600* for more information on using the recovery diskette.

Software

Enable the switch by following these steps:

- 1** Use your Web browser to navigate to the switch, and go to the Admin→File System display.
- 2** Click on the drive and click the Enable button.

Chapter 3

Contivity 2500/2000/4000 Option Installation

This section describes how to install or replace hardware components for the Contivity 2500, 2000, and 4000.



Warning: Wear an antistatic band when handling electronic components for the Contivity switch to avoid damaging them.



Note: Turn off the Contivity switch and unplug it before installing LAN or WAN cards, or system memory.

Opening the Contivity 2500/2000/4000

To install LAN or WAN cards, install hardware accelerator PCI cards, install additional memory, replace power supplies, or replace hard disk drives, you must remove the front bezel and then remove the switch's top cover. You may find it easier to work on the system when it has been removed from the rack.


Removing the Contivity 2500/2000/4000 front bezel

To access the Contivity 2500/2000/4000 disk drive for system recovery operations, you must first remove the switch's front bezel. [Figure 15](#) shows you how to remove the front bezel and top cover from the Contivity 2500/2000/4000.



Note: You do not need to turn off the switch to remove the front bezel.

Figure 15 Removing the Contivity 2500/2000/4000 front bezel



The first few times you remove the front bezel it will be rather difficult to remove. This is because the ball stud and sockets are new. After a few times, removal is easier. Sliding the top cover back is optional; it allows you to get a better grip on the front bezel for removal.

Remove the switch's front bezel as follows:


1. Optionally, remove the three screws at the top rear of the chassis, then slide the top cover back.
2. Slide your fingers between the front bezel and the switch.
3. Pull forward firmly.

Removing the Contivity 2500/2000/4000 top cover

Figure 16 shows you how to remove the top cover from the Contivity 2500/2000/4000. You must remove the cover to:

- Install LAN, WAN, or hardware accelerator cards
- Install additional memory

Figure 16 Removing the Contivity 2500/2000/4000 top cover



To remove the Contivity 2500/2000/4000 top cover:

- 1 Turn off the switch's power and unplug it.
- 2 Remove the three screws at the top rear of the chassis.
- 3 Slide the top cover back and move it away from the chassis.

Contivity 2500/2000/4000 system board layout

Figure 17 shows the Contivity 2500/200 system board, in particular the DIMMs, option card slots, and the CPU cooling fan. The Contivity 4000 system board is similar, but has **two** CPUs as shown in Figure 18.

Figure 17 Sample Contivity 2500/2000 system board






Figure 18 Sample Contivity 4000 system board



Installing Contivity 2500/2000/4000 LAN/WAN option cards

Figure 19 shows you how to install LAN or WAN option cards into a Contivity 2500/2000/4000. You can use Slots 1 to 3 for any mix of LAN and WAN cards. Note that Slot 4 is not supported.

Figure 19 Installing 2500/2000/4000 LAN/WAN option cards



CS2600017A


To install an option card:

- 1 Turn off the switch and remove the power cord.
- 2 Remove the front bezel and top cover as shown in [Figure 16](#).
- 3 Remove the filler panel screw and pull out the filler panel as shown in [Figure 19](#).
- 4 Slide the option card into the intended slot. Make sure the card seats firmly and evenly in the card slot. If the card is not seated properly, it will not work.
- 5 Replace the card and screw.
- 6 Replace the and top cover and front bezel.
- 7 Turn the switch on.

Installing Contivity 2500/2000/4000 DIMMs


[Figure 20](#) shows you how to unlock a Dual Inline Memory Module (DIMM) in a Contivity 2500/2000/4000, and remove or install a DIMM. Install a DIMM in the next available slot (for example, if the DIMM #1 slot is populated, add the next DIMM to the DIMM #2 slot).

Figure 20 Installing Contivity 2500/2000/4000 DIMMs



Replacing a Contivity 4000 power supply

[Figure 21](#) shows you how to replace a power supply for a Contivity 4000.

Figure 21 Removing a Contivity 4000 power supply

To remove a Contivity 4000 power supply, remove the switch's front bezel, then follow these steps:

- 1** Press the button down to turn off the power supply.
- 2** Press down on the release button.
- 3** Pull the handle forward.
- 4** Insert the new power supply. Make sure that the release button is pressed down while inserting the power supply.
- 5** Make sure the power supply is locked in.
- 6** Turn on the power supply and replace the front bezel.

Replacing a Contivity 4000 disk drive

To replace a Contivity 4000 disk drive, you must do the following:

Software

First save any data that has not yet been saved to the hard disk from the disk cache:

- 1 Use your Web browser to navigate to the switch, and go to the Admin→File System display.
- 2 Click the button “Prepare selected device for removal.”


Hardware

Remove the switch’s front bezel as shown in [Figure 15](#); then follow these steps:

- 1 To remove a Contivity 4000 hard disk drive, insert and turn the hard disk drive key to the right as shown in [Figure 22](#). The LED becomes a “U” for unlocked.



NOTE: Turning the key shuts off the power to the hard disk drive.

Figure 22 Removing a Contivity 4000 hard disk drive

- 2** Pull the handle to remove the hard disk drive.
- 3** Insert the replacement hard drive fully, and lock it by turning the key clockwise. Make sure the hard disk drive LED shows the proper drive number.
- 4** Replace the front bezel.
- 5** Reload the software on the disk. Refer to “Using the Recovery Diskette” in *Installing the Contivity 4600* for more information on using the recovery diskette.

Software


Enable the switch by following these steps:

- 1 Use your Web browser to navigate to the switch, and go to the Admin→File System display.
- 2 Click on the drive and click the Enable button.

Installing Contivity 2500/2000/4000 DIMMs

Figure 23 shows you how to unlock a Dual Inline Memory Module (DIMM) and remove or install the DIMM in the next available slot (for example, if the DIMM #1 slot is populated, add the next DIMM to the DIMM #2 slot).

Figure 23 Installing Contivity 2500/2000/4000 DIMMs



To replace or change a DIMM, follow these steps.

- 1** Turn off the switch.
- 2** Remove the power cord.
- 3** Remove the front bezel as shown in [Figure 15](#).
- 4** Remove the top cover as shown in [Figure 16](#).
- 5** Press down the locking levers on both sides of the next available slot to allow the new DIMM to be inserted.
- 6** Pull the DIMM up to remove it from the slot.
- 7** Place a new DIMM in the slot, making sure to properly position the DIMM's alignment keys. Make sure the DIMM is pressed firmly into the socket.
- 8** Pull up the locking levers on both sides of the DIMM, and snap the DIMM into the slot.
- 9** Replace the top cover.
- 10** Replace the front bezel.

Memory option

The Contivity 2500/2000/4000 ships with 128 Mbits of memory installed. An additional 128 Mbits can be installed. To increase the memory, contact Nortel Networks Customer Support.

Chapter 4

Contivity 2600 Option Installation

This section describes how to install or replace hardware components for the Contivity 2600.



Warning: Wear an antistatic band when handling electronic components for the Contivity switch to avoid damaging them.



Note: Turn off the Contivity switch and unplug it before installing LAN or WAN cards, or system memory.

Opening the Contivity 2600

To access the Contivity 2600 disk drive for system recovery operations, you must first remove the switch's front bezel. To install LAN or WAN cards, install hardware accelerator PCI cards, install additional memory, replace power supplies, or replace hard disk drives, you must remove the front bezel and then remove the switch's top cover. You may find it easier to work on the system when it has been removed from the rack.

Removing the Contivity 2600 front bezel




Note: Removing the front bezel on the Contivity 2600 system activates the chassis intrusion alarm whether or not the switch is turned on. This intrusion is reported to the system log file.

You must remove the bezel to insert the recovery diskette. Note that you **do not** need to turn off the switch if you are **only** removing the front bezel. [Figure 24](#) shows you how to remove the front bezel from the switch.



Caution: When handling the switch outside of the rack-mount shelf, do not use the part labeled with the Nortel Networks logo and the LEDs as a handle.

Figure 24 Removing the Contivity 2600 front bezel



CS260015A

The first few times you remove the front bezel it will be rather difficult to remove. This is because the ball studs and socket clips are new. After a few times, removal is easier.


To remove the front bezel, you need a Phillips screwdriver.

- 1** Turn each of the two screws on the front bezel a quarter turn counter-clockwise.
- 2** Grip the two handles and pull the bezel towards you firmly to unsnap it from the chassis.

Removing the Contivity 2600 top cover

To remove the cover to install LAN, WAN, or hardware accelerator cards or to install additional memory, you must remove the switch's front bezel and then you must remove the switch's top cover. [Figure 25](#) shows you how to remove the top cover from the switch.

Figure 25 Removing the Contivity 2600 top cover




CS260006A

- ➡ Slide the top cover forward approximately 1/4 inch, then lift the lid 2 to 3 inches and move it away from the chassis.

Contivity 2600 system board layout

Figure 26 shows the Contivity 2600's system board, in particular the DIMMs, option card slots, and the CPU cooling fan.

Figure 26 The Contivity 2600 system board

Warning: Beware of danger if battery is incorrectly replaced. Replace with the *same* or an *equivalent battery* only, as recommended by the manufacturer's instructions.




Danger: In spite of the above warning, which is mandated for regulatory approval, *you should not change the battery*. If you suspect a dead battery, contact Nortel Networks Customer Support.

Installing LAN/WAN and hardware accelerator option cards

Figure 27 shows you how to install LAN, WAN, or hardware accelerator option cards into the switch. You can use Slots 1 to 4 for any mix of LAN and WAN cards.

Figure 27 Installing LAN/WAN or hardware accelerator cards



CS2600017A

To remove the front bezel and cover, you need a Phillips screwdriver.

- 1 Power off the switch.
- 2 Remove the power cord.

- 3 Remove the front bezel as shown in [Figure 24](#).
- 4 Remove the top cover as shown in [Figure 25](#).
- 5 Remove the filler panel screw and pull out the filler panel as shown in [Figure 27](#).



Caution: Be careful when inserting option cards into the Contivity 2600, as the slide-out tray is not fully supported once pulled out. You should support the back of the tray with your hand while inserting an option card.

- 6 Slide the option card into the intended slot. Make sure the card seats firmly and evenly into the card slot. If the card is not seated properly, it will not work.
- 7 Replace the card and screw.
- 8 Replace the top cover.
- 9 Replace the front bezel.




Caution: Be careful when inserting option cards into the Contivity 2600, as the slide-out tray is not fully supported once pulled out. You should support the back of the tray with your hand while inserting an option card.

Installing Contivity 2600 DIMMs

Figure 28 shows you how to unlock a Dual Inline Memory Module (DIMM) and remove or install the DIMM in the next available slot (for example, if the DIMM #1 slot is populated, add the next DIMM to the DIMM #2 slot).

Figure 28 Installing Contivity 2600 DIMMs



To replace or change a DIMM, follow these steps.

- 1** Turn off the switch.
- 2** Remove the power cord.
- 3** Remove the front bezel as shown in [Figure 24](#).
- 4** Remove the top cover as shown in [Figure 25](#).
- 5** Press down the locking levers on both sides of the next available slot to allow the new DIMM to be inserted.
- 6** Pull the DIMM up to remove it from the slot.
- 7** Place a new DIMM in the slot, making sure to properly position the DIMM's alignment keys. Make sure the DIMM is pressed firmly into the socket.
- 8** Pull up the locking levers on both sides of the DIMM, and snap the DIMM into the slot.
- 9** Replace the top cover.
- 10** Replace the front bezel.

Memory option

The Contivity 2600 ships with 128 Mbits of memory installed. An additional 128 Mbits can be installed. To increase the memory, contact Nortel Networks Customer Support.

Chapter 5

Contivity 1600 Option Installation

This chapter describes how Nortel Networks trained service personnel can change existing hardware configurations, including installing LAN and WAN cards and how to add memory for the Contivity 1600.



Warning: Wear an antistatic band when handling electronic components for the Contivity switch to avoid damaging them.



Note: Turn off the Contivity switch and unplug it before installing LAN or WAN cards, or system memory.

Opening the Contivity 1600

To access the Contivity 1600's diskette drive for system recovery operations, you must first remove the switch's front bezel. To install LAN or WAN cards, install hardware accelerator PCI cards, install additional memory, replace power supplies, or replace hard disk drives, you must remove the front bezel and then remove the switch's top cover. You may find it easier to work on the system when it has been removed from the rack.

Removing the Contivity 1600 front bezel


You must remove the bezel to insert the recovery diskette. Note that you **do not** need to turn off the Contivity switch if you are only removing the front bezel.

Figure 29 shows you how to remove the front bezel from the Contivity switch.



Warning: When handling the Contivity switch outside of the rack-mount shelf, do not use the part labeled with the Nortel Networks logo and the LEDs as a handle.

Figure 29 Removing the Contivity 1600 front bezel



CS160014A

Note that the first few times you remove the front bezel it will be rather difficult to remove. This is because the ball studs and socket clips are new. After a few times, removal is easier.

To remove the front bezel you need a Phillips screwdriver.

- 1 Turn each of the two screws on the front bezel a quarter turn counter-clockwise.
- 2 Grip the two handles and firmly pull the bezel towards you to unsnap it from the chassis.

Removing the Contivity 1600 top cover

To install LAN or WAN cards, or to install additional memory, you must remove the Contivity 1600's front bezel and then the switch's top cover.

To remove the cover you need a Phillips screwdriver.




Note: You **do** need to turn off the Contivity switch to remove the top cover.

- 1 Turn off the switch's power and remove the power cord.

Figure 30 shows how to remove the power cord from the Contivity switch.


Figure 30 Removing the Contivity 1600 power cord



- 2 Turn each of the two screws on the front bezel a quarter turn counter-clockwise.
- 3 Grip the two handles and firmly pull the bezel towards you to unsnap it from the chassis. Do not use the part labeled with the Nortel Networks logo and the LEDs as a handle.

- 4 Use the Phillips screwdriver to remove the four screws that secure the cover to the chassis, as shown in [Figure 31](#).

Figure 31 Removing the Contivity 1600 top cover




CS160003A

- 5 Slide the top cover forward approximately 1/4 inch, then lift the lid 2 to 3 inches, and move it away from the chassis.

Contivity 1600 system board layout

Figure 32 shows the Contivity 1600's system board, in particular the DIMMs, option card slots, and the CPU cooling fan.

Figure 32 Contivity 1600 system board



Warning: Beware of danger if the battery is incorrectly replaced.

Replace with the *same* or an *equivalent* battery only, as recommended by the manufacturer's instructions.



Danger: In spite of the above warning, which is mandated for


regulatory approval, *you should not change the battery*. If you suspect a dead battery, contact Nortel Networks Customer Support.

Installing Contivity 1600 option cards

This section shows you how to install LAN or WAN option cards in the Contivity 1600.

- 1 Turn off the switch.
- 2 Remove the power cord, as shown in [Figure 33](#).

Figure 33 Removing the Contivity 1600 power cord




CS160009A

- 3 Remove the front bezel, as shown in [Figure 29](#).

- 4 Remove the top cover, as shown in [Figure 31](#).
- 5 Remove the filler panel screw and pull out the filler panel, as shown in [Figure 34](#).


Figure 34 Installing Contivity 1600 LAN/WAN option cards



CS160020A

- 6 Slide the option card into the intended slot, as shown in [Figure 35](#).
Make sure the card seats firmly and evenly into the card slot. If the card is not seated properly, it will not work.

Figure 35 Installing Contivity 1600 option cards




CS160019A

- 7** Replace the card and screw.
- 8** Replace the top cover.
- 9** Replace the front bezel.
- 10** Reconnect the power cord.
- 11** Turn on the switch.

Installing Contivity 1600 DIMMs

Figure 36 shows you how to unlock a DIMM and remove or install the DIMM in the next available slot (for example, if the DIMM # 1 slot is populated, then add the next DIMM to the DIMM # 2 slot).

Figure 36 Installing Contivity 1600 DIMMs



To replace a DIMM, follow these steps.

- 1 Turn off the switch.
- 2 Remove the power cord as shown in [Figure 30](#).
- 3 Remove the front bezel as shown in [Figure 29](#).
- 4 Remove the top cover as shown in [Figure 31](#).
- 5 Press down the locking levers on both sides of the DIMM as shown in [Figure 36](#).
- 6 Pull the DIMM up to remove it from the slot.
- 7 Place a new DIMM in the slot, making sure to properly position the DIMM's alignment keys. Make sure the DIMM is pressed firmly into the socket.
- 8 Pull up the locking levers on both sides of the DIMM, and snap the DIMM into the socket.
- 9 Replace the top cover.
- 10 Replace the front bezel.
- 11 Reconnect the power cord.
- 12 Turn on the switch.

Memory option

The Contivity 1600 ships with 64 Mbits of memory installed. An additional 64 Mbits can be installed. To increase the memory, contact Nortel Networks Customer Support.

Chapter 6

Contivity 600 Option Installation

This chapter describes how Nortel Networks trained service personnel can change existing hardware configurations, including installing LAN and WAN cards for the Contivity 600.



Note: The expansion slot is renamed to Slot 2 by the Contivity 600 software.



Warning: Wear an antistatic band when handling electronic components for the Contivity 600 to avoid damaging them.



Note: Unplug the power cord from the rear of the Contivity 600 before installing LAN or WAN interface cards.

To install LAN or WAN cards you must:


- 1 Remove the power cable.
- 2 Remove all signal cables.
- 3 Remove the four screws on the bottom of the switch.
- 4 Slide the inner chassis out of the casing.
- 5 Unscrew the PCI interface bracket screw and remove the PCI interface card or blank PCI bracket.
- 6 Install a new PCI interface, being careful to completely press the card into the PCI connector on the mother board.
- 7 Replace the chassis (along the guide rails) in the outer casing.
- 8 Replace the bottom screws.

- 9 Reconnect the power cord to turn the switch back on.

Opening the Contivity 600


To access the system, you must remove all cables, the power cord, and the bottom metal screws and pull the chassis from the rear. You need a Phillips screwdriver to access the system.

- 1 Unplug the switch's power cord from the back of the chassis and all the signal cables.
- 2 Turn the switch over to see the bottom of the box.
- 3 Using the Phillips screwdriver, remove the four screws that secure the bottom to the chassis, as shown in [Figure 37](#).

Figure 37 Removing the bottom screws

- 4 Firmly pull the chassis towards you to loosen it from the casing. You can gently shake it so that it slips outwards and into your hand or you can pull gently on the I/O expansion bay. [Figure 38](#) shows how to remove the system from the chassis.


Figure 38 Removing the system from the chassis



CS60004A

Contivity 600 system board layout

[Figure 39](#) shows the Contivity 600 system board, in particular the option card slot, DIMM memory, and the CPU cooling fan.

Figure 39 Contivity 600 system board

Warning: Beware of danger if the battery is incorrectly replaced.

Replace with the *same* or an *equivalent battery* only, as recommended by the manufacturer's instructions.



Danger: In spite of the above warning, which is mandated for regulatory approval, *you should not change the battery*. If you suspect a dead battery, contact Nortel Networks Customer Support.

Installing Contivity 600 option cards

This section shows you how to install LAN or WAN option cards in the Contivity 600.

- 1 Remove the blank PCI bracket by inserting a Phillips screw driver into the slot at the right of the blank PCI bracket and rotating the screw counter-clockwise.
- 2 Lift out the blank PCI bracket, and slide the replacement card into the intended slot.




Note: Be careful not to bend the copper fingers in the slot.

Make sure the card seats firmly and evenly in the card slot and that the left tabbed-end of the card is seated in its slot. If the card is not seated properly, it will not work.

- 3 Replace the screw at the right end of the PCI bracket.
- 4 Slide the system into the chassis as shown in Figure 40.

Figure 40 Replacing the system into the chassis



CS60004A

- 5 Replace the four Phillips-head screws to secure the bottom panel.
- 6 Reconnect the signal cables.
- 7 Reconnect the power cord to restart the Contivity 600.

Memory option

The Contivity 600 ships with 64 Mbits of memory installed. No additional memory can be installed.

Index

A

acronyms 16
additional memory
 installing 45
antistatic 19, 34

C

conventions 14
conventions, text 14
customer support 17

D

DIMMs 16, 22, 35
 installing 24, 38, 49, 54, 64, 75
documentation map 14
DSU/CSU
 required 16

F

front bezel
 removing 19, 20, 31, 32, 43, 44, 58, 68

H

hard drives 33

L

LAN cards
 installing 37, 45, 48, 62, 72, 81

M

memory
 size 55, 65, 76, 83

O

option cards slots 22, 35

P

power supplies 33
 replacing a 40
power supply
 replacing a 50
product support 17
publications
 hard copy 17

R

recovery diskette
 drive 33, 58, 68, 78

S

safety 19, 34
 power off 37, 39, 48, 55, 62, 65, 72, 76, 81
support, Nortel Networks 17
system board
 illustration 22, 35

T

technical publications 17
technical support 17

text conventions 14

top cover

removing 45

W

WAN cards

installing 37, 45, 48, 62, 72, 81